



CREATOR

31045



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.

[LEGO.com/creator](https://www.lego.com/creator)



1x

1



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA: PELIGRO DE ASFIXIA.
Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.



1x





1x



2x


2






1x

3



1x

4






2x



2x

5




4



2x


6





1x

7




1x



1x


8





4x

9



6




1x



1x

10





1x





1x



2x

11



1x




4x

12



2x






2x



2x

13



8




1x



2x

14






1x



1x

15




2x



2x

16





1x




1x



4x


1




2



3




17






2x

18



2x


19






1x

20




4x

21



22




2x



2x

23





1x



1x




1x




1x

24



6x

25






1x



1x

26



1x

27





1x

28



1x



1x

29






1x

30



1x




1x




1x

31



32






1x



1x

33



1x

34






1x

35



1x



1x

36





1x

37



1x



1x




1x

38



39






1x



1x

40




2x



2x

41





1x

42



1x


43






1x

44



2x


45





2x

46



1x




1x



1x

47





1x




1x

48



1x

49






1x



2x

50






1x




1x

51




1x

52



53






2x



2x

54





2x



1x

55




2x



2x

56







2x



1x


57



58




1x



2x


59






4x

60







2x
4533763



2x
287701



3x
6058177



3x
300401



1x
306901



2x
4585448



2x
4121932



2x
446001



2x
4610290



2x
301001



2x
4550745



3x
302001



2x
4243812



1x
379501



4x
4504379



1x
6075074



4x
4278275



1x
300321



8x
362321



2x
4251162



2x
4157223



2x
243121



2x
4178428



2x
302021



2x
303521



1x
4143005



1x
370024



4x
302324



1x
243224



2x
6029947



2x
302224



2x
6079007



1x
366024



3x
302124



2x
4184169



1x
6057397



1x
4121715



2x
302326



1x
4159335




1x
6007896



6x
371026



1x
300126



3x
4566179



2x
3005740



1x
4113949



3x
3005741



3x
3005748



4x
4244368



2x
4255413



10x
4504374



1x
4529954



1x
4502091



2x
6097498



2x
6103405



6x
4540280



2x
4568711



8x
4264569



1x
6127326



3x
4529241



4x
4211525



2x
4542590



2x
4211503



12x
4558953



1x
6071229



1x
6123815



2x
6066097



2x
6089147



4x
4211614



3x
6117967



3x
6043639



1x
6126082



6x
4211356



2x
6081975



1x
4211425



1x
4211051



4x
6055313



2x
4632574



2x
4210636



2x
6069164



4x
4210631



1x
4210935




1x
4212529



1x
4210884



2x
4598769



2x
4243831



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :





CREATOR



31045



31043

3 IN 1

LEGO.com/creator



club™

JOIN FREE TODAY!

JOIGNEZ-VOUS GRATUITEMENT !



MAGAZINE INCLUDES:

- > Building Ideas and Game Tips
- > Kids' Creations
- > Comic Adventures

LE MAGAZINE COMPREND :

- > Des idées de construction
- > Des créations super cool
- > Des bandes dessinées

LEGO.com/club | 1-877-518-5346

